



TACHTROL® plus Digital Remote Display

Part Number Series
T77810

CE
RoHS

TACHTROL plus :

- An extension of the **TACHPAK** and **TACHTROL** lines. While this device has no intrinsic tachometer function, it forms a network with **TACHPAK 10 & 30** and **TACHTROL 10 & 30** and can be used as a remote display or programming pendant.
- Serves as a gateway with both **TACHPAK** and **TACHTROL** instruments for secure, remote programming and alarm reset.
- Front panel operation and display is identical to **TACHTROL 10 & 30**
- Each display can be configured to display individual combinations of Channel A, B and Equation.
- Security can be applied to prevent unwanted access in remote locations.
- Acts as a hub for multiplexing up to seven additional displays with a single tachometer up to 125 feet away using an RJ11 (1:1) type phone cord.
- No external power connection. Connect only to approved **TACHTROL** and **TACHPAK** products.

Ordering P/N	Enclosure	Net Weight (lbs.)
T77810-10	Std. Panel Mount	0.6
T77810-40	NEMA 4X	3.7
T77810-70	Explosion Proof	42.0

It is the customer's responsibility to determine whether the product is proper for customer's use and application.